



Biro Tenderiser



#	SKU	Part Name	#	SKU	Part Name
1	305160	Safety Lid	19	302476	Waterproof Cap Nut
2	305100	3116 Front Comb	20	305001	Toggle Switch Cover
3	305102	3117 Back Comb	21	305150	On/Off Switch - TOGGLE
4	305101	3116L Rigid Front Comb (laser)	22	305123	Lid Switch Push Type
5	305103	3117L Rigid Back Comb (laser)	23	305281	Shaft End Shoulder Bearing - Back
6	305105	Stew/Stir Fry Back Comb 6mm Crossbar	24	305282	Shaft End Shoulder Bearing - Front
7	305106	Stew/Stir Fry Front Comb 6mm	25	305163	Lid Hinge - Left
8	305108	Stew / Stir Fry Front Comb 10mm 3/8,3/4	26	305164	Lid Hinge - Right
9	305109	Stew /Stir Fry Back Comb 10mm	27	305165	Lid Hinge Spring - Right side only
10	305122	Lid Switch Magnet Switch Black	28	305324	Foot Assembly
11	305110	Cutter Blade	29	305325	Knife Coupling with Pin
12	305115	Stir Fry Cutter Blade	30	305265	Shaft Drive - Back
13	305114	Stir Fry Feeder Teeth	31	305264	Shaft Drive - Front
14	305350	Drive Belt	32	305263	Knife Shaft - Back
15	305991	Cradle Assembly Complete - New	33	305262	Knife Shaft Front
16	305003	Stir Fry Set Assembly 6mm 1/4 Inch	34	305125	240V Solid State Relay
17	305004	Stir Fry Set Assembly 10mm 3/8 Inch	35	305124	On/Off Switch - Green/Red
18	305241	Shaft Circlip for 3/8 Shaft Stainless Steel	36	305128	Green/Red Switch Rubber Boot


**BUY
ONLINE!**

**For troubleshooting or assistance
Call us on 1300 88 99 51**





Safety Lid



3116 Front Comb



3117 Back Comb



Stew/Stir Fry Back Comb 6mm Crossbar



Stew/Stir Fry Front Comb 6mm



Stew / Stir Fry Front Comb 10mm 3/8, 3/4



Stew /Stir Fry Back Comb 10mm



Lid Switch Magnet Switch Black



Cutter Blade



Stir Fry Cutter Blade



Drive Belt



Cradle Assembly Complete - New



Toggle Switch Cover



On/Off Switch - TOGGLE



Shaft End Shoulder Bearing - Back



Shaft End Shoulder Bearing - Front



Lid Hinge - Left



Lid Hinge - Right



Lid Hinge Spring - Right side only



240V Solid State Relay



On/Off Switch - Green/Red